

# Direct Treater Air Daily Maintenance Log



Serial Number: \_\_\_\_\_

Week of : \_\_\_\_\_

Task	Mon	Tue	Wed	Thu	Fri	Sat	Sun
<b>DTA Daily Startup</b>							
Reinstall soaking nozzle parts into the DTA							
Check pretreatment level & shake bottle well							
Open pretreat valve (cleaner valve closed)							
Turn on DTA							
Use Purge/Load to fill tubing with pretreat							
<b>Operator Initials:</b>							
<b>DTA Daily Shutdown</b>							
Close pretreat valve & open cleaner valve							
Empty waste tank as needed							
Confirm that cleaner bottle at least 2/3 full with <i>Hyper Flush</i>							
Use <i>Clean</i> button to flush pretreat to waste tank until fluid throughout tubing is clear							
Turn off power switch							
Clean and lube the nozzle rail							
Remove the nozzle assembly							
Gently brush nozzle tip & mesh filter if necessary to remove any residue							
Soak the nozzle assembly components in sealed container of <i>Nozzle Cleaner</i>							
Wipe down DTA with Hyper Flush							
Wipe down rail with a clean dry cloth & lube							
<b>Operator Initials:</b>							

Please write the date maintenance was completed. If no maintenance was performed, leave the space blank.

## Direct Treater Air Periodic Maintenance Log

Serial number: \_\_\_\_\_

Task	Frequency	January	February	March	April	May	June	July	August	September	October	November	December
Replace nozzle tip	As needed												
Replace mesh filter	As needed												
Replace bottle filters	As needed												

Please write the date maintenance was completed. If no maintenance was performed, leave the space blank.

**Note: The above frequencies are suggestions only. Actual maintenance requirements may vary based on usage of your machine. For assistance on determining an appropriate schedule, please contact Tech Support.**