

Direct Treater Dual Daily Maintenance Log



Serial Number: _____

Week of : _____

Task	Mon	Tue	Wed	Thu	Fri	Sat	Sun
DTD Daily Startup							
Reinstall soaking nozzle parts into the DTD							
Check pretreatment levels & shake bottles well							
Open desired pretreat's valve (all others closed)							
Turn on DTD							
Use Purge/Load to fill tubes with pretreat							
Operator Initials:							
DTD Daily Shutdown							
Close pretreat valves & open cleaner valve							
Empty waste tank as needed							
Confirm that cleaner bottle at least 2/3 full with <i>Hyper Flush</i>							
Use <i>Clean</i> button to flush pretreat to waste tank until fluid throughout tubing is clear							
Turn off power switch							
Remove the nozzle assembly							
Gently brush nozzle tip & mesh filter if necessary to remove any residue							
Soak the nozzle assembly components in sealed container of <i>Nozzle Cleaner</i>							
Wipe down interior of DTD with Hyper Flush							
Wipe down all rails with a clean dry cloth & lube							
Operator Initials:							

Please write the date maintenance was completed. If no maintenance was performed, leave the space blank.

Direct Treater Dual Periodic Maintenance Log

Serial number: _____

Task	Frequency	January	February	March	April	May	June	July	August	September	October	November	December
Replace nozzle tip	As needed												
Replace mesh filter	As needed												
Replace bottle filters	As needed												

Please write the date maintenance was completed. If no maintenance was performed, leave the space blank.

Note: The above frequencies are suggestions only. Actual maintenance requirements may vary based on usage of your machine. For assistance on determining an appropriate schedule, please contact Tech Support.